

EPICFLAME Core 3 EPICFLAME Pro 4 EPICFLAME Pro 6



Abb.: EPICFLAME Pro 4


Art-Nr. 251164 / 251165 / 251166

support@roesle.de
www.roesle.com

DE	Montageanleitung
EN	Assembly Instructions
FR	Guide d'assemblage
IT	Istruzioni d'uso






EPICFLAME Core 3






EPICFLAME Core 3








EPICFLAME Pro 4






EPICFLAME Pro 4








EPICFLAME Pro 6






EPICFLAME Pro 6




1

EPICFLAME Pro 4
EPICFLAME Pro 6




2

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




3

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




4

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6





5

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6








6

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




7

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




8

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



9

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




10




EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



i




1




2

2

33



4



11

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




PH 2



2x E



2x K1




12

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



PH 2





7x A



12.2025



13

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



14



EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6







PH 2

7x A





16

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



17

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




18

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



PH 2

2x F




19

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




PH 2

4x H








20

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



21

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6





22

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6








2x G



23


EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6

1x K2




24



EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



25


EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6






27

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6





28

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




29

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6





30

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6





31A

EPICFLAME Core 3




32A

EPICFLAME Core 3





33A

EPICFLAME Core 3




34A

EPICFLAME Core 3




35A

EPICFLAME Core 3




36A

EPICFLAME Core 3





37A

EPICFLAME Core 3




38A

EPICFLAME Core 3




31B

EPICFLAME Pro 4
EPICFLAME Pro 6





32B

EPICFLAME Pro 4
EPICFLAME Pro 6






33B

EPICFLAME Pro 4
EPICFLAME Pro 6






34B

EPICFLAME Pro 4
EPICFLAME Pro 6







35B

EPICFLAME Pro 4
EPICFLAME Pro 6







36B

EPICFLAME Pro 4
EPICFLAME Pro 6







37B








EPICFLAME Pro 4
EPICFLAME Pro 6



38B


EPICFLAME Pro 4
EPICFLAME Pro 6






40

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



41




EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



42



EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6

1 x SW 17 mm
2 x SW 19 mm




43

EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6




44


EPICFLAME Core 3





45

EPICFLAME Pro 4







EPICFLAME Core 3
EPICFLAME Pro 4
EPICFLAME Pro 6



2 50mbar



3 30mbar



RÖSLE GmbH & Co. KG

Johann-Georg-Fendt-Straße 38
87616 Marktoberdorf
Germany

Phone: +49 8342 912-0

Fax: +49 8342 912-190

E-Mail: support@roesle.de

Web: www.roesle.com

Version 3

12/2025